

WSC Starting Lights - How to Operate

- Switch off everything
- Switch on the power switch at the back of the box
- Select the number of starts you want (normally 4)
- Five minutes before your 1st start switch on "Start"

the display will give you a countdown to each start if you want to use the flag boards simultaneously

- As each starts sequences through the horn will operate automatically
- If there is a individual recall you can make the light for that start flash until he/she or they have returned

you can, add the extra beep with the horn button (top right of the box)and you could display the individual recall board.

- If there is shipping or any other major event which requires you to delay the sequence, switch to "Pause". To continue switch back to "Start"

this will reset the sequence for the next start. You should make a note of the delay you have added to the sequence so that the handicap results can be calculated correctly

After the last start the display shows the stopwatch from the 1st start in seconds. Therefore you can note the time of each finisher and give them a beep when they finish.

If your eyesight finds the built-in display difficult to read then please connect up the old type stopwatch with the leads provided and reset it to zero. It will automatically be triggered by the 1st start.

If there is a General Recall you'll have to use the boards and start that fleet separately after all the others.